

Service at the indicated distance or time - whichever comes first.	km X 1,000	20	40	60	80	100	120	140	160	180	200
	months	12	24	36	48	60	72	84	96	108	120

**First service (1000km) check points**

Under hood	Under Body	Cabin	Tyres
1 Check engine oil level 2 Inspect battery condition (electrolyte level, load test) 3 Check <b>All fluid levels and condition of fluids</b> • Engine coolant • Brake fluid • Transmission fluid (CVTF/MTF) • Windshield washer fluid	1 Inspect exhaust system components 2 Inspect suspension components 3 Inspect drive shaft boots 4 Inspect brake hoses and lines (including abs/vsa) 5 Inspect tie rod ends, steering Gearbox and boots	1 Check lighting operation 2 Check operation of horn And air conditioning system 3 Check parking brake operation And brake pedal smooth operation	1 Check tyre inflation Including spare tyre

Replace engine oil	5,000 km or When indicator comes on or 3 months (which ever come first)* <sup>1</sup>
Replace engine oil filter	10,000 km or 6 Months* <sup>1</sup>
Replace air cleaner element	Every 20,000 km
Inspect valve clearance	Every 120,000 km* <sup>2</sup>
Replace spark plugs	Every 100,000 km
Inspect drive belts	• • • • •
Replace engine coolant	At 200,000 km or 10 years, thereafter every 100,000 km or 5 years
Add genuine injector cleaner agent* <sup>3</sup>	Every 10,000 km or 6 Months

**\*1:Conditions apply by using only Honda Genuine oil and oil filter**

\*2:Sensory Method

Adjust the valves during service 120,000 km if they are noisy.

\*3:Regular use of injector cleaner is required for models designated for Grand Cayman.